





**60
MNT**
























VISO BC60









A x6	B x6	C x6	D x8	E x12	F x6	G x4
						
H x8	J x2	K x4	L x8	M x14	N x8	P x4
 Ø4 X 14 mm				 M6 X 25 mm	 M6 X 20 mm	 M6 X 15 mm
Q x2	R x2	S x8	T x8	U x1	V x2	W x1
 Ø3 X 13 mm			 Ø 3.5 x 19 mm		 Ø3.5 X 19 mm	 L4


1




2




3




4




5







6





7




D x 8	N x 8	P x 4	W x 1
	 M6 X 20 mm	 M6 X 15 mm	 L4

8



M x 14
 M6 X 25 mm





9





L x 8




10



11



12

**ATTENTION**

- * Wall mounting screw is not provided. please source the right fitting according to the wall type.
- * Factory is not responsible for wrong installation or wrong wall fitting usage.