


# KOZU RAK DISPLAY




01:30

Lama Perakitan 90 Menit

2 Orang Untuk Merakit

















Perkakas Tambahan







No.	Size	Qty
1	1156 x 357 x 15 mm	1
2,4	596 x 357 x 15 mm	2
3	580 x 298 x 15 mm	1
5,15	1193 x 357 x 15 mm	3
6,7,8,9	20 x 0.7 x 1151 mm	4
10	400 x 20 x 1796 mm	2
11	400 x 20 x 1068 mm	1

NO.	SIZE	QTY.
12	55x20x1151 mm	2
13	55 x 46 x 94 mm	1
14	1147 x 357 x 15 mm	1
16,17	572 x 385 x 15 mm	2
18	138 x 30 x 15 mm	2
19	575 x 575 x 15 mm	2
20	570 x 297 x 15 mm	2


## ACCESSORIES

					
Ax12	Bx12	Cx10	Dx46	Ex12	Fx4
					
Gx12	Hx4	Ix4	Jx4	Kx4	Lx4
					
Mx8	Nx5	Ox1	Px1		





1







2







# 3






# 4






5







6





7




8




9




NEED 2 PERSON TO FLIP



Ex1





Ox1




BACK


10




Dx4




Hx4





lx4



Ox1





11




Mx8


12



Dx4



Kx4



Lx4




Nx4






# 13


**STEP 1** Straighten bottom side door to the under rail








**STEP 2** Straighten bottom side door to the under rail




**STEP 3** Press down the switch of sliding guide to adjust the door and to the rail then release to the lock.



# 14




Dx2



Jx4





Nx1




Px1

15



Ex3



Ox1

16

